



Technical Data Sheet:
Odorless White Spirit 600

Code:
1110

Ref.: ST110
Rev.: 10
Date:
09/02/2018

Product Type:

Thinner for synthetic or oleo-synthetic odorless paints

Formats:

Tanks 1000 liters,
Drums 200 liters,
Cans 25 - 10 - 5 - 1 - 0.5 liters.

Product Characteristics:

A blend of special dearomatized aliphatic hydrocarbons (without aromatic hydrocarbons), which has a very tolerable and faint odor, so much so that it can be called ODORLESS.

Technical Specifications of the Product:

CHARACTERISTIC	UM	VALUE	METHOD	TOLERANCE
Physical state	Liquid		Visual	//
Color	Colorless clear		Visual	//
Density at 20°C	Kg/dm ³	0.777	Met. Int. ISTR. 44	± 0.01
Water content	%	0.02	Met. Int. ISTR. 48	Maximum
Flash point	°C	28	Met. Int. ISTR. 53	Typical

Use / Applications:

It is widely used in the dilution of odorless synthetic and oleo-synthetic enamels, especially in operations to be carried out INDOORS, thus in all those environments where a faint odor and maximum respect for the environment and the operator are required.

In addition to a good solvent power, slow evaporation allows the paint to expand and spread perfectly, giving the artifact a perfect shine.

And also:

It is also used in the fine arts for diluting waxes. It can be used as a degreaser and cleaner of surfaces prior to painting, as a wax remover and silicone remover for surfaces including painted or plastic-coated surfaces, to remove oils, grease, tar, to clean equipment for painting, for DIY.

For degreasing, washing and cleaning operations in the bodywork sector, please refer to products that comply with Italian Legislative Decree No. 161 of March 27, 2006.

How to use:

Dilute the enamel to the desired viscosity for the chosen application. Thicker for brush or roller, more liquid for spray application. Approximately between 10 and 20 %, unless there are different indications printed on the paint can.

Additional Information:

To have better flow and shine of the enamel and eliminate brush marks, add 5 % FIDOIL to replace the thinner. Mix carefully with a palette knife.

The above information is provided based on our theoretical and practical knowledge. The company, however, does not assume any liability as the conditions of use and application are not subject to the control of Fidea SpA